

Description for WiFi+Sensor Cooldown procedure

Procedure for cooldown temperature documentation.



Start-up procedure on cooling process.

There are 2 push buttons on the front of the unit as well as a display.

The **left button** starts the temperature reading and initiates the cooling log.

The **right button** is used to select fixed texts according to which text is to be associated with the document.

When the first text is shown on the display, press repeatedly to select between the texts found in the device.

When the correct text is found in the display, no further actions are required, then the cooling log has started.

For each press, the device will scroll through the texts that have been created, and when the text to be used is found, no more pressing. After a few seconds the device will upload the start signal and text to the server, and the cooling logging is started.

The cooling log cannot be stopped; however, the Left button can be pressed for any extra temperature loggings during cooling.

After 4 hours, or at the first measured Temperature below 10 °C the process stops automatically, and a Mail/Notification will be sent to inform you that the cooldown is completed and that a report has been

created. You can find the report on the web portal under the menu "Views/Cooling".

When the process is stopped, the WiFi+Sensor unit will go to sleep for 24 hours, unless a new cooldown process is started again by pressing the buttons as described above.

Explanations of symbols in the display:



Searching Network



Not saved on server (try again)



Data saved on server

Changes to the fixed texts.

The texts in the device can be changed as follows:

Enter the Webportal.

Select the Department >" Where the device is located."

Select the menu > "SENSORS"

1. Press Edit on the sensor number.
2. Press the small (+) button at the top of the comments, and an empty block will be added at the bottom.
3. Up to three lines can be written on each text block.
4. Please do not use strange characters and do not use Danish letters "æøå". Real letters only.

Go to the bottom and press **SAVE**

The small (-) button removes text block.

Existing text blocks can be corrected, just remember to go to the bottom and press **SAVE** after the corrections.