

## Description for WiFi+Sensor Single measurement procedure



Start-up procedure on Single measurement with WiFi+Sensor unit  
Goods received, or Buffet food.

**Food control:** Insert the sensor in the food core, wait 15 sec. Then Press the left button. If Temp. are OK then continue with the Right button see below. If not OK then try again.

**Goods control:** Insert the sensor in between the goods, wait 20 sec. Then Press the left button. If Temp. are OK then continue with the Right button see below. If not OK then try again.

The **left button** starts the temperature reading.

The **right button** is used to select fixed texts according to which text is to be associated with the measurement. Push the right button when you see a small check mark in the display.

When the first text is shown on the display, press repeatedly to select between the texts found in the device.

When the correct text is found in the display, no further actions are required.

When the process is stopped, the WiFi+Sensor unit will go to sleep for 24 hours, unless a new measurement is started.

**Explanations of symbols in the display:**



Searching Network



Not saved on server (try again)



Data saved on server

### Changes to the fixed texts.

The texts in the device can be changed as follows:

#### Enter the Webportal.

Select the Department >" Where the device is located."

Select the menu > "SENSORS"

1. Press Edit on the sensor number.
2. Press the small (+) button at the top of the comments, and an empty block will be added at the bottom.
3. Up to three lines can be written on each text block.
4. Please do not use strange characters and do not use Danish letters "æøå". Real letters only.  
Go to the bottom and press **SAVE**

The small (-) button removes text block.

Existing text blocks can be corrected, just remember to go to the bottom and press **SAVE** after the corrections.